

SPECIFICATION




Features:

- Universal AC input/Full range
- ZVS new technology
- · AC input active surge current limiting
- Built-in active PFC function,PF>0.95
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Forced air cooling by built-in DC ball bearing fan
- High power density 8.3W/inch³
- Output voltage can be trimmed between 20% ~ 110% rated value
- Current sharing up to 4500W(2+1)
- · Alarm signal output
- Built-in 12V/0.1A auxiliary output for remote control
- Built-in remote ON-OFF control
- · Built-in remote sense function

Parallel & cMus & Back CBC &

MODEL		SPV-1500-12	SPV-1500-24	SPV-1500-48			
	DC VOLTAGE	12V	24V	48V			
	RATED CURRENT	125A	63A	32A			
	CURRENT RANGE	0 ~ 125A	0 ~ 63A	0 ~ 32A			
	RATED POWER	1500W	1512W	1536W			
	RIPPLE & NOISE (max.) Note.2	150mVp-p	150mVp-p	200mVp-p			
OUTPUT	VOLTAGE ADJ. RANGE	±5% typical adjustment by VR, 20% ~ 110% (typ.) adjustment by 1~6VDC external control signal					
	VOLTAGE TOLERANCE Note.3						
	LINE REGULATION		±0.5%				
	LOAD REGULATION	±0.5%					
	SETUP, RISE TIME	1500ms, 100ms at full load					
	HOLD UP TIME (Typ.)	10ms at full load 14ms at full load 16ms at full load					
	, , ,	90 ~ 264VAC 127 ~ 370VDC	141113 at full load	Toms at full load			
	FREQUENCY RANGE	47 ~ 63Hz					
INDUT	POWER FACTOR (Typ.)	0.95/230VAC 0.98/115VAC at full loa		00%			
INPUT	EFFICIENCY (Typ.)	86.5%	90%	90%			
	AC CURRENT (Typ.)	17A/115VAC 8A/230VAC					
	INRUSH CURRENT (Typ.)	30A/115VAC 60A/230VAC					
	LEAKAGE CURRENT	<2.0mA / 240VAC					
	OVERLOAD	105 ~135% rated output power					
	OVERLOAD	Protection type: Constant current limiting, recovers automatically after fault condition is removed					
DDOTECTION	OVER VOLTAGE	13.8 ~ 16.8V	30 ~ 34.8V	57.6 ~ 67.2V			
PROTECTION	OVER VOLIAGE	Protection type : Shut down o/p voltage, re-power on to recover					
	OVER TEMPERATURE	105°C ±5°C (TSW2) detect on heatsink of power transistor					
	OVERTENIFERATORE	rotection type : Shut down o/p voltage, recovers automatically after temperature goes down					
	AUXILIARY POWER(AUX)	12V@0.1A(Only for Remote ON/OFF control)					
FUNCTION	REMOTE ON/OFF CONTROL	Please see the Function Manual					
FUNCTION	ALARM SIGNAL OUTPUT	Please see the Function Manual					
	OUTPUT VOLTAGE TRIM	2.4 ~ 13.2V	4.8 ~ 28V	9.6 ~ 56V			
	WORKING TEMP.	-20 ~ +70°C (Refer to "Derating Curve")					
	WORKING HUMIDITY	20~90% RH non-condensing					
ENVIRONMENT	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH					
	TEMP. COEFFICIENT	±0.05%/°C (0~50°C)					
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. eac	ch along X, Y, Z axes				
	SAFETY STANDARDS	UL60950-1, TUV EN60950-1 approved					
SAFETY &	WITHSTAND VOLTAGE	I/P-O/P:3KVAC					
EMC	ISOLATION RESISTANCE	1/P-O/P, 1/P-FG, O/P-FG:100M Ohms / 500VDC / 25°C / 70% RH					
(Note 4)	EMC EMISSION	Compliance to EN55022 (CISPR22), EN61000-3-2,-3					
	EMC IMMUNITY	Compliance to EN61000-4-2,3,4,5,6,8,11, EN55024, light industry level, criteria A					
	MTBF	109K hrs min. MIL-HDBK-217F (25°C)					
OTHERS	DIMENSION	278*127*83.5mm (L*W*H)					
	PACKING	3.0Kg; 4pcs/13Kg/1.19CUFT					
NOTE	All parameters NOT special Ripple & noise are measure Tolerance: includes set up The power supply is consid EMC directives. For guidan (as available on http://www.	set up tolerance, line regulation and load regulation. set up tolerance, line regulation and load regulation.					





AC Input Terminal Pin No. Assignment

Pin No.	Assignment
1	FG ±
2	AC/N
3	AC/L

Control Pin No. Assignment(CN1,CN2): HRS DF11-8DP-2DS or equivalent

Pin No.	Assignment	Pin No.	Assignment	Mating Housing	Terminal
1	RCG	5,7	-S		
2	RC2	6	LS(Current Share)	HRS DF11-8DS	HRS DF11-**SC
3	PV	8	+S	or equivalent	or equivalent
4	PS				

RCG: Remote ON/OFF Ground

-S: -Remote Sensing

RC2: Remote ON/OFF

LS: Load Share

PV: Output voltage external control

+S: +Remote Sensing

PS: Reference voltage terminal, PS and PV are connected when shipping


Control Pin No. Assignment(CN3): HRS DF11-6DP-2DS or equivalent

Pin No.	Assignment	Pin No.	Assignment	Mating Housing	Terminal
1	P OK GND	4	AUXG	LIDO DE44 0D0	UD0 DE44 **00
2	POK	5	RC1	or equivalent	HRS DF11-**SC
3	RCG	6	AUX	or equivalent	or equivalent

P OK GND: Power OK Ground P OK: Power OK Signal RCG: Remote ON/OFF Ground

AUXG: Auxiliary Ground RC1: Remote ON/OFF AUX: Auxiliary Output

■ Block Diagram





PFC fosc: 70KHz



■ Derating Curve

■ Static Characteristics





■ Function Manual

1.Remote ON/OFF


- (1)Remote ON/OFF control becomes available by applying voltage in CN1 & CN2 & CN3
- (2) Table 1.1 shows the specification of Remote ON/OFF function
- (3)Fig.1.2 shows the example to connect Remote ON/OFF control function

Table 1.1 Specification of Remote ON/OFF


Connection Method		Fig. 1.2(A)	Fig. 1.2(B)	Fig. 1.2(C)
SW Logic	Output on	SW Open	SW Open	SW Close
SW Logic	Output off	SW Close	SW Close	SW Open

Fig.1.2 Examples of connecting remote ON/OFF


(A)Using external voltage source



(B)Using internal 12V auxiliary output



(C)Using internal 12V auxiliary output





2. Alarm Signal Output

- (1) Alarm signal is sent out through "P OK" & "P OK GND" pins
- (2)An external voltage source is required for this function. The maximum applied voltage is 50V and the maximum sink current is 10mA
- (3) Table 2.1 explains the alarm function built-in the power supply

· · · · · · · · · · · · · · · · · · ·						
Function	Description	Output of alarm(P OK)				
P OK	The signal is "Low" when the power supply is above 15% of the rated output voltage-Power OK	Low (0.5V max at 10mA)				
FOR	The signal turns to be "High" when the power supply is under 15% of the rated output voltage-Power Fail	High or open (External applied voltage 10mA max.)				

Table 2.1 Explanation of alarm function







Fig. 2.2 Internal circuit of P OK (Open collector method)

3.External Voltage Control







Note: Reference voltage terminal, PS and PV are connected when shipping $\,$

4. Current Sharing

- (1)Parallel operation is available by connecting the units shown as below (+S,-S and LS are connected mutually in parallel):
- (2) The voltage difference among each output should be minimized that less than ±2% is required
- (3)The total output current must not exceed the value determined by the following equation (Output current at parallel operation)=(The rated current per unit) x (Number of unit) x 0.9
- (4) In parallel operation 3 units is the maximum, please consult the manufacturer for other applications
- (5) When remote sensing is used in parallel operation, the sensing wire must be connected only to the master unit

Note: In parallel connection, maybe only one unit (master) operate if the total output load is less than 5% of rated load condition.

The other PSUs (slaves) may go into standby mode and their output LEDs will not turn on.

